

DirectLine® DL421 Sensor Module
***for* Durafet® II, Durafet® III,**
Meredian® II, and HPW7000 pH
Electrodes
User Manual

70-82-25-102

Rev. 5

2/04

Notices and Trademarks

Copyright 2004 by Honeywell
February, 2004

Warranty/Remedy

Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is **in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose**. Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

CE Conformity

This product is in conformance with the protection requirements of the following European Council Directives: 89/336/EEC, the Electromagnetic Compatibility Directive and 73/23/EEC, the Low Voltage Directive. Conformance of this product with any other "CE Mark" Directive(s) shall not be assumed.

ATTENTION

The emission limits of EN 61326 are designed to provide reasonable protection against harmful interference when this equipment is operated in an industrial environment. Operation of this equipment in a residential area may cause harmful interference. This equipment generates, uses and can radiate radio frequency energy and may cause interference to radio and television reception when the equipment is used closer than 30 m to the antenna(e). In special cases, when highly susceptible apparatus is used in close proximity, the user may have to employ additional mitigating measures to further reduce the electromagnetic emissions of this equipment.

Industrial Measurement and Control

Honeywell
1100 Virginia Ave.
Fort Washington, PA 19034

DirectLine is a registered trademark of Honeywell

Durafet and Meredian are U.S. registered trademarks of Honeywell

Other brands or product names are trademarks of their respective owners

Insert 70-82-10-01 should accompany this document.

About This Document

Abstract

This manual contains all the information that is needed to install, configure, calibrate, operate, and troubleshoot the DirectLine® Sensor. Insert 70-82-10-01, a quick reference guide for configuring and calibrating the DL421, should accompany this document.

Contacts

World Wide Web

The following lists Honeywell's World Wide Web sites that will be of interest to our customers.

| Honeywell Organization | WWW Address (URL) |
|------------------------------------|---|
| Corporate | http://www.honeywell.com |
| Industrial Measurement and Control | http://www.honeywell.com/imc |
| International | http://www.honeywell.com/Business/global.asp |



Telephone

Contact us by telephone at the numbers listed below.

| Organization | | Phone Number | |
|--------------------------|-----------|----------------------------------|----------------------------------|
| United States and Canada | Honeywell | 1-800-423-9883 (215) 641-3610 | <i>Tech. Support</i> |
| | | 1-888-423-9883 | <i>Q&A Faxback (TACFACS)</i> |
| | | 1-800-525-7439 | <i>Service</i> |

Symbol Definitions

The following table lists any symbols used in this document to denote certain conditions.

| Symbol | Definition |
|---|--|
|  | Earth Ground. Functional earth connection. NOTE: This connection shall be bonded to Protective earth at the source of supply in accordance with national and local electrical code requirements. |
|  | ATTENTION, Electrostatic Discharge (ESD) hazards. Observe precautions for handling electrostatic sensitive devices |

Contents

| | |
|--|-----------|
| 1. INTRODUCTION | 1 |
| 1.1 Overview | 1 |
| 1.2 Electronics Module | 1 |
| 1.3 Operator Interface..... | 2 |
| 1.4 Specifications..... | 3 |
| 1.5 Model Selection Guide | 4 |
| 2. INSTALLATION | 5 |
| 2.1 Assembly and Wiring | 5 |
| 2.2 Integral Mounting | 7 |
| 2.3 Remote Mounting | 8 |
| 2.4 Conduit connections | 13 |
| 3. CONFIGURATION | 14 |
| 3.1 Overview | 14 |
| 3.2 Configuration Set Up Procedure..... | 15 |
| 4. CALIBRATION | 18 |
| 4.1 Calibration Diagnostics | 18 |
| 4.2 Calibration Diagnostic Reset | 18 |
| 4.3 Calibration..... | 19 |
| 4.4 Calibration in High Purity Water | 22 |
| 5. OPERATION | 23 |
| 5.1 Displays | 23 |
| 5.2 Diagnostic Error Messages | 25 |
| 5.3 Unit Reset..... | 26 |
| 6. SPARE PARTS | 27 |
| 7. APPENDIX: CE MARK APPLICATIONS | 30 |
| 8. SALES AND SERVICE | 32 |

Tables

| | |
|---|----|
| Table 2-1 Assembly and Wiring Procedure for Field Wiring Connector | 6 |
| Table 2-2 Integral Mounting Procedure (refer to Figure 2-3) | 7 |
| Table 2-3 Remote Mounting Procedure for Durafet II and Durafet III Electrodes | 8 |
| Table 2-4 Remote Mounting Procedure for Meredian II Electrodes | 9 |
| Table 2-5 Remote Mounting Procedure for HPW7000 Electrodes | 10 |
| Table 3-1 Buffer Groups and the pH standard values | 14 |
| Table 3-2 Configuration Set Up Procedure | 15 |
| Table 4-1 Standard pH Buffer Values | 20 |
| Table 4-2 Zero (Standardization) Calibration Procedure | 21 |
| Table 4-3 Slope Calibration Procedure | 22 |
| Table 4-4 High purity water calibration Procedure | 22 |
| Table 5-1 Online Parameter Descriptions | 23 |
| Table 5-2 Display Navigation Procedure | 24 |
| Table 5-3 Online Diagnostic Errors | 25 |
| Table 5-4 Factory Default Values | 26 |

Figures

| | | |
|------------|---------------------------------|----|
| Figure 1-1 | DirectLine® Sensor | 1 |
| Figure 1-2 | Electronics Module | 2 |
| Figure 2-1 | Cordset Connection and Wiring | 5 |
| Figure 2-2 | Field Wiring Connector | 6 |
| Figure 2-3 | Integral Mounting | 7 |
| Figure 2-4 | Remote Mounting | 11 |
| Figure 2-5 | Remote Mounting Hardware | 12 |
| Figure 7-1 | Wiring for CE Mark Applications | 30 |

1. Introduction

1.1 Overview

The DirectLine® Sensor consists of an **electronics module** connected to a **Durafet® II, Durafet® III, Meredian® II or HPW7000 pH electrode** that eliminates the need for pre-amps, transmitters, and analyzers in pH applications.

The modular electronics design can be separated from the sensor, allowing the sensor to be easily removed or replaced while retaining power to the electronics module.

The DL421 **electronics module** is contained in a Nema Type 4x polysulfone housing. The Module can be mounted as an integral unit directly connected to the electrode or remotely using an electrode with a cable. The sealed plastic housing has plug-in connections for the pH electrode and 4-20 mA cordset.

Figure 1-1 DirectLine® Sensor

1.2 Electronics Module

The electronics module is loop-powered by 16-42 Vdc and will modulate its supply current from 4 mA to 20 mA, depending upon the pH value that is sensed by the electrode. The transmitted loop current is compensated for temperature internally using the standard Honeywell 8550 thermistor.

For submersion or special wiring applications, the remote electronics module is compatible with the existing Durafet II, Meredian II or HPW7000 technology without modification. A Durafet II or Meredian II cable length is supported with direct connection to the electronics module.

A 4-20 mA output connection is provided via a 6m cordset or a customer supplied cable used in combination with a field wiring connector.




Figure 1-2 Electronics Module

1.3 Operator Interface

The DirectLine® Sensor operator interface consists of three pushbuttons and one 4-digit, 7-segment LCD display with 3 decimal points, plus (+), and minus (–) signs. It is responsible for the display of measured values and configuration of parameter values.

1.4 Specifications

| | |
|---|---|
| Displayed pH | 0-14 pH |
| Displayed Temperature Range | –10 °C to +110 °C (14 °F to 230 °F) |
| Process Temperature | –10 °C to +110 °C (14 °F to 230 °F) |
| Sensor Survivable Temperature Range Durafet II & III Meridian II | –10 °C to +130 °C (14 °F to 266 °F) 0 °C to 110 °C (32 °F to 230 °F) |
| Electronics Module Ambient Temperature | –20 °C to +85 °C (–4 °F to +185 °F) |
| Output Type | 4-20 mA (2-wire loop powered) |
| Output Scale | 0-14 pH |
| Output Calibration | 4-20 mA |
| Mating Connector Rating | Submersible to 6.1m (20') |
| Output (Loop) | 6m (19.7') cordset or Shielded twisted pair with field wiring connector |
| User Termination | Tinned leads |
| Cable Lengths Sensor: | <i>Durafet II & Durafet III:</i> 6.1m (20') or 15.24m (50') <i>Meridian II:</i> 3.65m (12') or 6.1m (20') <i>HPW7000:</i> .45m (1.5') or 10.97m (36') |
| Power | 16-42 Vdc, 23mA max <i>Maximum load resistance:</i> 250 ohms at 16 Vdc 600 ohms at 24 Vdc 1400 ohms at 42 Vdc |
| Local Display and Buttons | LCD 4-digit, 7-segment |
| Engineering Units | pH degrees F degrees C |
| Calibration Options | 1 point Sample or 2 point Sample Auto Buffer Recognition <i>Selections:</i> US, NIST, EURO |
| Solution Temperature Compensation | <i>Selections:</i> 0.00pH/10°C –0.16pH/10°C –0.32pH/10°C |
| Diagnostics | Sensor and electronics |
| Case | Weatherproof, corrosion-resistant plastic housing, NEMA4X |
| Approvals | CE Mark for Industrial Applications UL – General Purpose for Process Control CSA – General Purpose FM – CLI, DIV1, Groups A, B, C & D and CLI, Zone 0 AEx ia IIC (IS) FM – CLI, DIV2, Groups A, B, C & D and CLI, Zone 2, Groups IIC (N.I. Field Wiring) |
| Remote Mounting | Pipe, Wall, or DIN Rail |
| Dimensions | H 123 mm (4.84") x W 48 mm (1.89") x D 46 mm (1.81") |
| Weight | Approximately 142 g (5.0 oz.) |

1.5 Model Selection Guide

Instructions

- Select the desired key number. The arrow to the right marks the selection available.
- Make the desired selections from Tables I through IV using the column below the proper arrow. A dot (•) denotes availability.

Key Number I II III IV
 [] - [] - [] - [] - []

Key Number - DirectLine® Sensor Electronics Module

(Specify electrodes/cells/probes separately)

| | |
|--------------|--|
| pH | For use with Durafet II, Meridian II & HPW7000 pH electrodes |
| ORP | For use with ORP electrode |
| Conductivity | For use with Contacting Conductivity Cells |
| DO - PPM | For use with Dissolved Oxygen ppm Probes |
| DO - PPB | For use with Dissolved Oxygen ppb Probes |

| Selection | Availability | | | | |
|-----------|--------------|---|---|---|---|
| DL421 | ↓ | | | | |
| DL422 | | ↓ | | | |
| DL423 | | | ↓ | | |
| DL424 | | | | ↓ | |
| DL425 | | | | | ↓ |

TABLE I - OUTPUT CABLE

| | |
|--|---|
| Output Cable for Integral or Remote Mounting | None (replacement module or customer supplied output cable)- Note 1 |
| | Cordset - 6m (19.7 ft.) - includes connector and cable - Note 2 |
| | Field Wiring Connector only - customer supplies cable only - Note 2 |

| | | | | | |
|---|---|---|---|---|---|
| D | • | • | • | • | • |
| E | • | • | • | • | • |
| F | • | • | • | • | • |

TABLE II - SENSOR CABLE/REMOTE CONNECTOR (between electronic module and electrode, sensor or probe)

| | |
|--|--|
| Integral Mounting | No cable or connector required |
| Remote Mounting Cable - Durafet Only | 6,096m (20 ft.) of sensor cable - Durafet II Remote Mtg w/PWB connector 6,096m (20 ft.) of sensor cable-Durafet III Remote Mtg w/Vario Pin connector- Note 3 15,24m (50 ft.) of sensor cable - Durafet II Remote Mtg w/PWB connector 15,24m (50 ft.) of sensor cable - Durafet III Remote Mtg w/Vario Pin connector- Note 3 |
| Remote Mounting Connector (Cable is supplied with sensor or probe) | Remote Mounting Connector - Meridian II pH Remote Mounting Connector - Meridian II ORP Remote Mounting Connector - HPW7000 Remote Mounting Connector - Conductivity Remote Mounting Connector - Dissolved Oxygen |

| | | | | | |
|---|---|---|---|---|---|
| 0 | d | d | d | d | d |
| 1 | e | | | | |
| 7 | e | | | | |
| 2 | e | | | | |
| 8 | e | | | | |
| 3 | e | | | | |
| 3 | | e | | | |
| 4 | e | | | | |
| 5 | | | e | | |
| 6 | | | | e | e |

TABLE III - REMOTE MOUNTING OPTIONS

| | |
|----------------------------------|---|
| Mounting Kit for Remote Mounting | None Integral unit - mounting not required 2" (5.08 cm) Pipe mtg. bracket, wall mtg. & DIN Rail clip |
|----------------------------------|---|

| | | | | | |
|---|---|---|---|---|---|
| A | • | • | • | • | • |
| B | • | • | • | • | • |

TABLE IV - OPTIONS

| | |
|--------------|---|
| Tagging | None SS Customer ID Tag - 3 lines w/22 characters/line |
| Certificates | None Calibration & Conformance |

| | | | | | |
|------|---|---|---|---|---|
| 00__ | • | • | • | • | • |
| SS__ | • | • | • | • | • |
| __00 | • | • | • | • | • |
| __CC | • | • | • | • | • |

Notes:

- Customers may procure their own output cordsets from the vendors listed below.
- Customers may make their own 4-20 mA output cordset using a 2-wire twisted shielded pair, and M12 field wiring connector procured from one of the vendors listed below. Use only UV rated outdoor cable to maintain NEMA 4 rating.

| | Phoenix Contact | Turck |
|----------------------------|----------------------------------|--------------|
| Cordset | SAC-3P-5.0-PUR/M12FSSH Stainless | RKV4T-6/S618 |
| M12 Field Wiring Connector | SACC-M12FS-4CON-PG7 | B8141-0 |
| Cable | 2-wire twisted shielded pair | |

- Durafet III cables with Vario Pin connector require Durafet III electrode with Vario Pin connector

RESTRICTIONS

| Restriction Letters | Available Only With | | Not Available With | |
|---------------------|---------------------|-----------|--------------------|-----------|
| | Table | Selection | Table | Selection |
| d | III | A | | |
| e | III | B | | |

ORDERING INSTRUCTIONS:

- Part numbers are provided to facilitate Distributor Stock.
- Orders may be placed either by model selection or by part number.
- Part numbers are shown within the model selection tables to assist with compatibility information.
- Orders placed by model selection are systematically protected against incompatibility.
- Compatibility assessment is the responsibility of the purchaser for orders placed by part number.
- Items labeled as N/A are not available via the stocking program and must be ordered by model selection.

2. Installation

2.1 Assembly and Wiring

Depending on the customer selected output cable options, the DirectLine can be wired to an appropriate 16-42 Vdc source using 2 different methods:

- 1) cordset
- 2) field wiring with customer supplied cable.

Refer to Section 7 for wiring for CE Mark applications.

2.1.1 Cordset




Figure 2-1 Cordset Connection and Wiring

2.1.2 Field Wiring

Refer to Figure 2-2. The field wiring connector supports customer supplied cable with an outer diameter of 4-6mm.

Table 2-1 Assembly and Wiring Procedure for Field Wiring Connector

| Step | Procedure |
|----------|---|
| 1 | Disassemble field wiring connector a) Unscrew parts to separate pressure screw, clamp type cage, gasket, housing and female insert. |
| 2 | Insert customer supplied cable through connector parts a) Slide pressure screw over skin and tinned customer cable (note orientation). b) Slide clamp type cage over cable (note orientation). c) Slide gasket over cable. d) Slide housing over cable (note orientation). |
| 3 | Connect wires to pins Look closely at end of female insert to locate pin numbers. Connect positive wire to pin 1 and negative wire to pin 4. Remaining wires and female insert pins 3 and 2 are unused. |
| 4 | Assemble field wiring connector a) Screw female insert to housing until female insert's o-ring is compressed. b) Slide clamp type cage/gasket into housing. c) Thread pressure screw into housing until $\frac{1}{4}$ turn past finger tight. |
| 5 | Connect cable to source Wire the other end of the Output cable to a 16-42 Vdc source as indicated in Figure 2-1. Note: your wire colors may be different. |




Figure 2-2 Field Wiring Connector

2.2 Integral Mounting

Table 2-2 Integral Mounting Procedure (refer to Figure 2-3)

| Step | Procedure |
|---|---|
| Connect Electrode to Pipe and Electronics Assembly | |
| 1 | Screw the electrode into the pipe tee (3/4 " NPT thread). Make sure that the final position of the installed electronics module allows the display to be easily viewed by plant personnel. |
| 2 | Align the slots in the electronics module with those in the electrode and press down to connect the electronics to the electrode. |
| 3 | Tighten the locking screw on the bottom rear of the electronics module. |





Figure 2-3 Integral Mounting

2.3 Remote Mounting

Table 2-3 Remote Mounting Procedure for Durafet II and Durafet III Electrodes

| Step | Procedure (Refer to Figure 2-4 and Figure 2-5) |
|------|---|
| 1 | Apply a thin film of silicon grease to the ID of electronics module's remote mounting cavity. |
| 2 | Connect Remote Sensor Wiring Cable to the Remote Electronics Housing <ol style="list-style-type: none"> Remove the cover from the remote cable connector. Align the slots in the cable connector housing with those in the electronics module and push up to connect the cable to the electronics module. Tighten the locking screw on the rear of the electronics module. Make sure the connector is completely seated. |
| 3 | Secure Electronics Module with Wall, Pipe, or DIN Rail Mounting <p>Mount bracket with clips facing forward, smaller clip on top and larger clip on bottom.</p> <p><i>Wall:</i> Use one of three through-holes to secure to wall.</p> <p><i>Pipe:</i> Feed hose clamp through two slots and secure to pipe.</p> <p><i>DIN rail:</i> Attach the appropriate DIN rail clip to the mounting bracket: "U" DIN rail—use metal clip and shorter screw (8 mm) "G" DIN rail—use gray clip and longer screw (10 mm)</p> <p>Clip can be rotated for horizontal or vertical DIN rails.</p> <p>Push electronics module onto the remote mounting bracket until it snaps into position.</p> |
| 4 | Connect Remote Sensor Wiring Cable to the Remotely Mounted Electrode <p>Durafet II with PC Board type connector:</p> <ol style="list-style-type: none"> Remove cover from the remote cable connector. Loosen the ferrule and slide back the ferrule, small O-ring, and plastic cover to expose the remote cable connector. Align the cable connector keyway with the electrode key (small black tab on the top of the electrode). Slide the plastic cover over the electrode end and hand-tighten the cover onto the electrode. Be careful not to cross the threads of the connector. Slide the O-ring and ferrule down the cable to the back of the cover cap. Hand-tighten the ferrule onto the cover cap. <p>-OR-</p> <p>Durafet III with Vario Pin, 11 conductor connector:</p>  <p>Electrostatic Discharge (ESD) hazards. Observe precautions for handling electrostatic sensitive devices.</p> <ol style="list-style-type: none"> Remove cover from the cable connector. Make sure electrode connector and cable connector are clean and dry. Align keyway of Vario Pin connector on electrode with tab inside mating connector on cable. Press cable connector onto electrode firmly. Tighten knurled busing of cable connector by hand to ensure waterproof seal. |

When the DL421 is specified with Table II = 3, the Remote Connector Assembly (part number 51500768-001) is supplied loose for connection of the Meredian II pH electrode cable to the DL421 module. Table 2-4 gives the mounting procedure.

Table 2-4 Remote Mounting Procedure for Meredian II Electrodes


| Step | Procedure (Refer to Figure 2-4 and Figure 2-5) |
|------|---|
| 1 | Turning counterclockwise, remove strain relief/cover combination from the remote connector assembly. |
| 2 | Remove the protective plastic bag from the end of the electrode cable. Be careful to keep bare fingers away from coax cable termination. |
| 3 | Loosen and remove compression cap from strain relief fitting. Carefully push cable end through cap and strain relief fitting so that these parts are strung back along cable jacket. |
| 4 | Connect cable leads as follows: Terminal 1 = Orange Reference Electrode Lead Terminal 2 = White Temperature Compensation Lead Terminal 3 = White Temperature Compensation Lead Terminal 4 = Pigtail Shield Lead Terminal 5 = NC (No Connection) Terminal 6 = Coax Measuring Electrode Lead Earth Ground = Yellow |
| 5 | Slide cover along cable and tighten by hand onto the remote connector assembly. |
| 6 | Slide cap along cable and tighten onto cable jacket with small wrench until cable cannot slide within strain relief rubber bushing. |
| 7 | Remove yellow protective sleeve from opposite end of connector assembly. |
| 8 | Apply a thin film of silicon grease to the ID of electronics module's remote mounting cavity. |
| 9 | Plug remote connector assembly into DL421 module aligning polarity tab of module housing and mating groove on connector. |
| 10 | Secure Electronics Module with Wall, Pipe, or DIN Rail Mounting Mount bracket with clips facing forward, smaller clip on top and larger clip on bottom. <i>Wall:</i> Use one of three through-holes to secure to wall. <i>Pipe:</i> Feed hose clamp through two slots and secure to pipe. <i>DIN rail:</i> Attach the appropriate DIN rail clip to the mounting bracket: "U" DIN rail—use metal clip and shorter screw (8 mm) "G" DIN rail—use gray clip and longer screw (10 mm) Clip can be rotated for horizontal or vertical DIN rails. Push electronics module onto the remote mounting bracket until it snaps into position. |

When the DL421 is specified with Table II = 4, the Remote Connector Assembly (part number 51500768-002) is supplied loose for connection of the HPW7000 electrode cables to the DL421 module. Table 2-5 gives the mounting procedure.

Table 2-5 Remote Mounting Procedure for HPW7000 Electrodes


| Step | Procedure (Refer to Figure 2-4 and Figure 2-5) |
|-------------|--|
| 1 | Turning counterclockwise, remove strain relief/cover combination from the remote connector assembly. |
| 2 | Remove the protective plastic bag from the end of the measuring electrode cable. Be careful to keep bare fingers away from coax cable termination. |
| 3 | Loosen and remove compression cap from strain relief fitting. Carefully push all 3 cable ends through cap and strain relief fitting so that these parts are strung back along cable jacket. |
| 4 | <p>Connect cable leads as follows:</p> <ul style="list-style-type: none"> Terminal 1 = Clear Reference Electrode Coax Lead Terminal 2 = Black Temperature Compensation Lead Terminal 3 = White Temperature Compensation Lead Terminal 4 = Black/White Measuring Electrode Coax Shield Terminal 5 = Clear Measuring Electrode Coax Lead Terminal 6 = No Connection Earth Ground = (3) Green/White Leads from Measuring, Reference and Temperature |
| 5 | Slide cover along cables and tighten by hand onto the remote connector assembly. |
| 6 | Slide cap along cables and tighten onto cable jackets with small wrench until cables cannot slide within strain relief rubber bushing. |
| 7 | Remove yellow protective sleeve from opposite end of connector assembly. |
| 8 | Apply a thin film of silicon grease to the ID of electronics module's remote mounting cavity. |
| 9 | Plug remote connector assembly into DL421 module aligning polarity tab of module housing and mating groove on connector. |
| 10 | <p>Secure Electronics Module with Wall, Pipe, or DIN Rail Mounting</p> <p>Mount bracket with clips facing forward, smaller clip on top and larger clip on bottom.</p> <p><i>Wall:</i> Use one of three through-holes to secure to wall.</p> <p><i>Pipe:</i> Feed hose clamp through two slots and secure to pipe.</p> <p><i>DIN rail:</i> Attach the appropriate DIN rail clip to the mounting bracket: "U" DIN rail—use metal clip and shorter screw (8 mm) "G" DIN rail—use gray clip and longer screw (10 mm)</p> <p>Clip can be rotated for horizontal or vertical DIN rails.</p> <p>Push electronics module onto the remote mounting bracket until it snaps into position.</p> |

Electronics Module



Remote Electronics Module for Durafet II or III Electrodes



Electronics Module



Remote Electronics Module for Meridian II Electrodes and HPW7000

Meridian II Electronics

- | | |
|---|---|
| 1 | Orange Reference Electrode Lead |
| 2 | White Temperature Compensation Lead |
| 3 | White Temperature Compensation Lead |
| 4 | Pigtail Shield Lead |
| 5 | 1 Meg-ohm resistor (pre-installed by Honeywell) |
| 6 | Coax Measuring Electrode Lead and 1 Meg-ohm resistor (pre-installed by Honeywell) |



HPW7000 Electronics

- | | |
|---|-------------------------------|
| 1 | Clear Reference Coax Lead |
| 2 | Black Temperature Sensor Lead |
| 3 | White Temperature Sensor Lead |
| 4 | Black/White Measuring Shield |
| 5 | Clear Measuring Coax Lead |
| 6 | No Connection |

Note: Three Green/White leads to DL421 mounting bracket screw. Mounting bracket must be connected to earth ground.

Figure 2-4 Remote Mounting




Figure 2-5 Remote Mounting Hardware

2.4 Conduit connections

The DirectLine provides a male $\frac{1}{2}$ " NPT thread to accommodate a customer conduit connection. Use $\frac{1}{2}$ " conduit coupling (min. 38.1mm (1.5") long) on DL conduit connection to clear cordset connector. Conduit can not be used with field wiring connector due to size restriction.

Do not exceed 200in-lb. torque when attaching fixed piping.

Use wrench flats provided under the $\frac{1}{2}$ " NPT threads to support the DirectLine during installation.

3. Configuration

3.1 Overview

Configuration Parameters

Set Up consists of configuring the following functions:

- **Buffer Group Selection** – Only used with Auto Buffer Recognition calibrations. Determines the set of standard pH buffer values to be used for Zero (standardization) and Slope calibration by automatic buffer recognition. Each of the available Buffer Groups is a set of 5 pH buffer standards that you can select.
The available groups are: US (*default*), NIST, and EURO.

Table 3-1 Buffer Groups and the pH standard values

| Buffer Group | pH Buffers | | | | | Display |
|--------------|------------|------|------|------|-------|---------|
| US (default) | 2 | 4 | 7 | 10 | 12 | US |
| NIST | 1.68 | 4.01 | 6.86 | 9.18 | 12.45 | nISt |
| EURO | 1 | 3 | 6 | 8 | 10 | Euro |

- **Solution Temperature Coefficient** – Typically only used in power plants for condensate/feedwater applications. Measured pH is displayed and transmitted to a pH value normalized to what the pH value would be if the temperature of the process was 25 °C. Magnitude of normalization is dependent upon the Solution Temperature coefficient, expressed in units of pH/10 °C with precision to the hundredth decimal place.
The three available values are: 0.00 (*standard setting, default*), –0.16 pH/10 °C (*pure water*), and –0.32 pH/10 °C (*condensate/feedwater*).
- **Noise Suppression Frequency Selection** – Selection of 50 Hz or 60 Hz.
Defaults to 60 Hz at unit reset.
- **Output Configuration** – The following Output Configuration functions can be selected:
 - ❑ **0% Range** 0 % Range values can be adjusted within a range 0.00 to 14.00 pH in 0.50 pH increments.
 - ❑ **100% Range** 100 % Range values can be adjusted within a range 0.00 to 14.00 pH in 0.50 pH increments.
 - ❑ **0% Calibration** Output current can be typically adjusted to within a range of 3.80 mA to 4.40 mA.
 - ❑ **100% Calibration** Output current can be typically adjusted to within a range of 19.60 mA to 20.40 mA.

3.2 Configuration Set Up Procedure

ATTENTION:

In Table 3-2, under the **Press** column:



- **Hold** means to hold the button down until the display changes.
- **Momentarily** means to press and release the indicated button.












From the Online pH display, follow this procedure.




ATTENTION:

If no key is pressed for 60 seconds, the display will abort the entry mode and default to Online Display.

Table 3-2 Configuration Set Up Procedure

| Step | Operation | Press | Display |
|------|---|---|--|
| 1 | Enter Buffer Group Selection | MODE Hold | bFrG (for 1 second) then, (Current Buffer Group Selection) |
| | Edit Buffer Group | MODE Hold | Flashing Display – You are now in EDIT mode (Value of current Buffer Group selection) |
| | Select desired Buffer Group |  Momentarily | To select US (default), NIST , or Euro |
| | Save the Buffer Group | MODE Momentarily | Selection for group |
| 2 | Enter Solution Temperature Coefficient Selection | MODE Momentarily | COEF (for 1 second) then, (Solution Temperature Coefficient Selection) |
| | Edit Solution Temperature Coefficient | MODE Hold | Flashing Display – You are now in EDIT mode (Value of current Coefficient selection) |
| | Select desired Coefficient |  Momentarily | To select: 0.00 pH/10°C (default) or –0.16 pH/10°C (pure water) –0.32 pH/10°C (AVT, Amine, Phosphate or Oxygenated Treatment) |
| | Save the Solution Temperature coefficient | MODE Momentarily | Selection for coefficient |

| Step | Operation | Press | Display |
|------|--|---|--|
| 3 | Enter Noise Suppression Frequency | MODE Momentarily | nSUP (for 1 second) then, (Noise Suppression Frequency Selection) |
| | Edit Noise Suppression Frequency | MODE Hold | Flashing Display – You are now in EDIT mode (Value of current Frequency selection) |
| | Select desired Frequency |   Momentarily | To select 50 Hz or 60 Hz (default) |
| | Save the Noise Suppression Frequency | MODE Momentarily | Selection for frequency |
| 4 | Enter Output Configuration | MODE Momentarily | OutC Enter Output Calibration |
| | 0% Range Value Selection |  Momentarily | rnGL (for 1 second) then, (value of current 0 % Range Value Selection) |
| | Edit 0 % Range Value Selection | MODE Hold | Flashing Display – You are now in EDIT mode Value of current 0 % selection) |
| | Select desired 0 % pH Value |   Momentarily | Selected 0 % pH Value in 0.50 pH increments Range: 0.00 to 14.00 pH (default 0.00) |
| | Save the New 0 % Range Value | MODE Momentarily | (New Value) |
| 5 | 100 % Range Value Selection |  Momentarily | rnGH (for 1 second) then, (value of current 100% Range Value Selection) |
| | Edit 100 % Range Value Selection | MODE Hold | Flashing Display – You are now in EDIT mode (value of current 100 % selection) |
| | Select 100 % pH Value |   Momentarily | Selected 100 % pH Value in 0.50 pH increments Range: 0.00 to 14.00 pH (default 14.00) |
| | Save the New 100 % Range Value | MODE Momentarily | (New Value) |
| 6 | 0 % Calibration |  Momentarily | AdJL |
| | Adjust 0 % Calibration | MODE Hold | AdJL (flashes) – You are now in EDIT mode Range: 3.80 to 4.40 mA typically (default 4.00 mA) |
| | |   Momentarily | +AdJL (increments value) –AdJL (decrements value) |
| | Save 0 % Calibration | MODE Momentarily | AdJL |

| Step | Operation | Press | Display |
|------|--------------------------|---|---|
| 7 | 100 % Calibration |  Momentarily | AdJH |
| | Adjust 100 % Calibration | MODE Hold | AdJH (flashes) – You are now in EDIT mode Range: 19.60 to 20.40 mA typically (default 20.00 mA) |
| | |   Momentarily | +AdJH (increments value) –AdJH (decrements value) |
| | Save 100 % Calibration | MODE Momentarily | AdJH |
| 8 | Return to Online Display | MODE Momentarily | Returns to Online Display |

4. Calibration

4.1 Calibration Diagnostics

Introduction

The manual and automatic standardization and slope adjustments change the zero offset and the percent theoretical slope calibration diagnostics used by this system. These values are viewed as read-only information. It is good practice to observe these values after calibration. Monitoring the values over time will help you predict when the electrode will need to be replaced.

Zero Offset pH Value

When Online pH value is displayed, **PRESS**  button momentarily to display the current **Zero Offset value** in fixed hundredths decimal position.

Zero Offset is non-volatile and is initialized to 0.00 pH at unit reset.

It has a range of -2.00 pH to +2.00 pH and it is updated after each calibration.

Percent Theoretical Slope Value

When Online pH value is displayed, **PRESS**  button momentarily to display the current **Percent Theoretical Slope value** in fixed tenths decimal position.

Percent Theoretical Slope is non-volatile and is initialized to 100.0 % at unit reset.

It has a range of 80.0 % to 105.0 % and it is updated after each calibration.

60 Second Timeout

If no key is pressed for 60 seconds, the display will abort the entry mode and default to Online Display.

4.2 Calibration Diagnostic Reset

Introduction

When a new electrode is installed, the indicated pH will use the zero offset and percent theoretical slope values from the previous calibration. Depending on the condition of the replaced electrode, the difference between the known and indicated pH of the new electrode may vary as much as several pH units. A calibration on the new electrode will correct this difference.



ATTENTION:

If Auto Buffer Recognition (ABR) calibration is used when the new electrode is calibrated for the first time, the ABR calibration may select a buffer value from the selected standard buffer group table (Table 4-1) that is directly above or below the actual buffer value.

To avoid this discrepancy, follow one of the two procedures listed below:

1. Select the correct buffer value by following Step 2B of Table 4-3.
 2. Perform a calibration diagnostic reset as described below prior to performing an ABR calibration on the new electrode.
-

Zero Offset pH Value and Percent Theoretical Slope Value

- a) Momentarily press  to view the Zero Offset value. From this display press and hold the  button until the Zero Offset pH value resets to factory default “0.00”. The Percent Theoretical Slope value resets to factory default “100.0” at the same time (approximately 10 seconds).
- b) Press MODE button, or wait 60 seconds, to return to Online pH.

4.3 Calibration

Overview

ATTENTION:

If a Solution Temperature Compensation Coefficient was selected per Configuration Section 3.2, this coefficient is disabled while calibration is being performed.

Calibration consists of the following functions:

- **Calibrating the Zero (Standardization)** – Manual or automatic pH calibration. In auto calibration, you can select one of the other buffer pH values directly above or below the recognized buffer value in the current buffer group. (See Table 4-1.)
- **Calibrating the Slope** - Manual or automatic pH calibration. In auto calibration, you can select one of the other buffer pH values directly above or below the recognized buffer value in the current buffer group. (See Table 4-1.)

Table 4-1 Standard pH Buffer Values

| Temp °C | | 0 | 5 | 10 | 15 | 20 | 25 | 30 | 35 | 40 | 45 | 50 |
|------------------------|---------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| <i>Group</i> | <i>Buffer</i> | | | | | | | | | | | |
| US (default) | 2 | 2.01 | 2.01 | 2.01 | 2.01 | 2.00 | 2.00 | 2.00 | 2.00 | 2.00 | 2.00 | 2.00 |
| | 4 | 4.01 | 3.99 | 4.01 | 3.99 | 4.00 | 4.00 | 4.01 | 4.02 | 4.03 | 4.04 | 4.05 |
| | 7 | 7.13 | 7.10 | 7.07 | 7.05 | 7.02 | 7.00 | 6.99 | 6.98 | 6.97 | 6.97 | 6.97 |
| | 10 | 10.34 | 10.26 | 10.19 | 10.12 | 10.06 | 10.00 | 9.94 | 9.90 | 9.85 | 9.82 | 9.78 |
| | 12 | 12.60 | 12.44 | 12.28 | 12.14 | 12.00 | 11.88 | 11.79 | 11.66 | 11.53 | 11.43 | 11.32 |
| NIST | 1.68 | 1.67 | 1.67 | 1.67 | 1.67 | 1.68 | 1.68 | 1.68 | 1.69 | 1.69 | 1.70 | 1.71 |
| | 4.01 | 4.01 | 4.00 | 4.00 | 4.00 | 4.00 | 4.01 | 4.01 | 4.02 | 4.03 | 4.04 | 4.06 |
| | 6.86 | 6.98 | 6.95 | 6.92 | 6.90 | 6.88 | 6.86 | 6.85 | 6.84 | 6.84 | 6.83 | 6.83 |
| | 9.18 | 9.48 | 9.40 | 9.33 | 9.28 | 9.23 | 9.18 | 9.14 | 9.10 | 9.07 | 9.04 | 9.01 |
| | 12.45 | 13.42 | 13.21 | 13.01 | 12.80 | 12.64 | 12.45 | 12.30 | 12.13 | 11.99 | 11.84 | 11.71 |
| EURO | 1 | 0.98 | 0.98 | 0.99 | 0.99 | 1.00 | 1.00 | 1.01 | 1.01 | 1.01 | 1.01 | 1.02 |
| | 3 | 3.02 | 3.02 | 3.02 | 3.02 | 3.00 | 3.00 | 2.99 | 2.99 | 2.98 | 2.98 | 2.97 |
| | 6 | 6.03 | 6.02 | 6.01 | 6.00 | 6.00 | 6.00 | 6.00 | 6.01 | 6.02 | 6.04 | 6.05 |
| | 8 | 8.15 | 8.11 | 8.07 | 8.03 | 8.00 | 7.97 | 7.94 | 7.91 | 7.88 | 7.87 | 7.86 |
| | 10 | 10.22 | 10.17 | 10.12 | 10.05 | 10.00 | 9.95 | 9.90 | 9.86 | 9.82 | 9.78 | 9.74 |

Calibration Procedures

ATTENTION:

CAL2 must be done within 10 minutes of **CAL1**, otherwise **CAL1** must be repeated to enable **CAL2**.

ATTENTION:

In Table 4-2 and Table 4-3, under the **Press** column:

- **Hold** means to hold the button down until the display changes.
- **Momentarily** means to press and release the indicated button.

Table 4-2 Zero (Standardization) Calibration Procedure















| Step | Operation | Press | Display |
|-----------|---|---|--|
| 1 | Enter Zero (Standardization) Calibration |  Hold | CAL1 For Sample (Manual) calibration, go to step 2A . OR For Auto Buffer Recognition calibration, go to step 2B . |
| 2A | Do Sample (Manual) Calibration |  Momentarily | SCAL for one second, then displays Live Buffer Value. |
| | Edit Buffer Value |  or  Momentarily | To edit Buffer Value (<i>Flashing Display</i>) |
| | Save New Buffer Value | MODE Momentarily | Buffer Value is saved and goes to Online Display . |
| OR | | | |
| 2B | Do Auto Buffer Recognition Calibration |  Hold | ACAL for one second, then displays closest Group Buffer Value. (<i>Flashing Display until stable reading is achieved</i>) |
| | Edit Group Buffer Value |  or  Momentarily | “New Value” – Selects ± 1 buffer group (<i>Flashing Display until stable reading is achieved</i>) then goes to Online Display . |

Table 4-3 Slope Calibration Procedure

| Step | Operation | Press | Display |
|-----------|---|---|--|
| 1 | Enter Slope Calibration |  Hold | CAL2 For Sample (Manual) calibration, go to step 2A . OR For Auto Buffer Recognition calibration, go to step 2B . |
| 2A | Do Sample (Manual) Calibration |  Momentarily | SCAL for one second then, displays Live Buffer Value |
| | Edit Buffer Value |  or  Momentarily | To edit Buffer Value (<i>Flashing Display</i>) |
| | Save New Buffer Value | MODE Momentarily | Buffer Value is saved and goes to Online Display . |
| OR | | | |
| 2B | Do Auto Buffer Recognition Calibration | Hold  | ACAL for one second then, displays closest Group Buffer Value (<i>Flashing Display until stable reading is achieved</i>) |
| | Edit Group Buffer Value |  or  Momentarily | “New Value” – Selects ± 1 buffer group (<i>Flashing Display until stable reading is achieved</i>) then goes to Online Display |

4.4 Calibration in High Purity Water

When the DirectLine module is used with the HPW7000 High pHurity Water Assembly an addition calibration step may be required. This involves doing an independent check of the pH with a portable lab meter and then, if necessary, a Sample Cal to correct the reading.

Table 4-4 High purity water calibration Procedure

| Step | Procedure |
|------|---|
| 1 | Perform a 2-point calibration using either the Auto Buffer Recognition Calibration or Manual Calibration per section 4.3. |
| 2 | Return the HPW7000 electrodes to the flow chamber and restart flow to the chamber. |
| 3 | Allow the flow chamber to “clean out” by flowing sample through the chamber for at least an hour. |
| 4 | Check the pH of the process using a portable instrument that uses a flowing reference type electrode. Make sure the sample is not exposed to air, otherwise the pH due to absorption of carbon dioxide from the air. |
| 5 | If necessary adjust the HPW7000 pH to agree with the portable instrument reading by doing a 1-point Sample Cal per section 4.3. |

5. Operation

5.1 Displays

Overview

The DirectLine® DL421 displays the pH value, Temperature, Zero Offset pH value, and Percent Theoretical Slope online. The table below describes these parameters.

Table 5-1 Online Parameter Descriptions

| Parameter | Description |
|--|---|
| Online pH | Measured pH expressed with fixed hundredths decimal precision. Range: 0.00 to 14.00 |
| Online Temperature | Measured temperature expressed with fixed tenths decimal precision. Temperature displayed in °C or °F Range: –10.0 to 110.0 °C –14.0 to 230.0 °F |
| Zero Offset pH Value | Zero Offset pH value expressed with fixed hundredths decimal precision. Range: –2.00 to +2.00 pH |
| Percent Theoretical Slope Value | Percent Theoretical Slope value expressed with fixed tenths decimal precision. Range: 80.0 % to 105.0 % |

The default display and home position is the **Online pH** display. It appears when:

- *The unit is powered up*
- *No button presses for 60 seconds*
- *A successful Zero (Standardization) or Slope calibration has occurred in **Auto Buffer Recognition***
- *The Mode button has been pressed during Zero (Standardization) or Slope calibration (**Sample Calibration**)*
- *The Mode button has been pressed during a configuration edit*

The measurement and display of pH is updated at a rate of 500 ms.

ATTENTION:

In Table 5-2, under the **Press** column:

- **Momentarily** means to press and release the indicated button.

Table 5-2 Display Navigation Procedure

| Step | Operation | Press | Display |
|------|--|--|---|
| 1 | View Online pH value | MODE Momentarily | <i>(measured pH)</i> |
| 2 | View Online Temperature | MODE Momentarily | <i>(measured temperature in °C or °F)</i> Proceed to step 2A or step 3 . |
| 2A | Toggle Online Temperature display units | ▲ or ▼ Momentarily | <i>(measured temperature in °C or °F)</i> Proceed to step 3 . |
| 3 | Return to home position | MODE Momentarily | <i>(measured pH)</i> |

5.2 Diagnostic Error Messages

When a diagnostic error or status condition occurs, the Online Display alternates between measured pH and a text message.

Table 5-3 Online Diagnostic Errors

| What you see | What it is | What to do |
|---|---|--|
| CNFG | Data error detected. | Reset unit or cycle power. Second occurrence will show FALT. |
| FALT | Unit electronics are defective. | Replace electronics module. |
| <i>These errors may occur when online pH or temperature is displayed.</i> | | |
| P HI | Measured pH is > 14.00 pH | Bring process within limits |
| P LO | Measured pH is < 0.00 pH | Bring process within limits |
| PRBE | Probe is defective, removed from process, or not connected. Forces the output to burnout level (greater than 21.8 mA). | Check probe, connection and presence of sample. When the source of the error is removed, the error will clear and the output will return to normal operation. |
| T HI | Measured temperature is > 110 °C | Bring process within limits |
| T LO | Measured temperature is < -10 °C | Bring process within limits |
| <i>These errors may occur during probe calibration and abort the calibration process.</i> | | |
| FAIL | These error messages are preceded by the message "FAIL" BFRS The Slope buffer is less than 2 pH from Zero (Standardization) buffer. SRNG The Slope calibration failed due to a calculated Percent Theoretical Slope value outside the range of 80.0 % to 105.0 %. STBL The Zero (Standardization) or Slope calibration failed due to measured pH instability. TRNG The Zero (Standardization) or Slope calibration failed due to solution temperature outside the range of 0 °C to 50 °C. (Auto Buffer Recognition calibration only) ZRNG The Zero (Standardization) calibration failed due to a calculated Zero Offset value outside the range of -2.00 pH to 2.00 pH. | Press Mode to return to online display. |

5.3 Unit Reset

Overview

Unit Reset initializes all of the DirectLine® Sensor's calibration and configuration data to factory default values.

Procedure

- From the Online pH display, press and hold the ▲ and ▼ buttons simultaneously until “rSEt” appears on the display (**minimum of 10 seconds**).
- “rSEt” will remain on the display until reset is complete. Next, the firmware version number appears briefly and the unit then returns to the Online pH display.

Table 5-4 Factory Default Values

| Data | Default Values |
|--|--------------------|
| Zero Offset | 0.00 pH |
| Slope | 100.0 % |
| Online Temperature | °C |
| Buffer Group Selection | US |
| Solution Temperature Coefficient Selection | 0.00 pH/10 °C |
| Noise Suppression Frequency Selection | 60 Hz |
| Output Configuration – 0 % Range Value | 0.00 pH |
| Output Configuration – 100 % Range Value | 14.00 pH |
| Output Configuration – 0 % Calibration | 4.00 mA typically |
| Output Configuration – 100 % Calibration | 20.00 mA typically |

6. Spare Parts

| Part Number | Description |
|--------------|---|
| 51452682-001 | DirectLine® DL421 Sensor Module (Replacement Module) |
| 51452683-001 | 6 m cordset |
| 51452684-002 | Field Wiring connector (supports customer supplied cable (4-6mm OD)) |
| 51500270-001 | Remote Electrode Mounting Cable – 20 foot (Durafet II only) |
| 51500270-002 | Remote Electrode Mounting Cable – 50 foot (Durafet II only) |
| 51453225-001 | Remote Electrode Mounting Cable – 20 foot (Durafet III only) |
| 51453225-002 | Remote Electrode Mounting Cable – 50 foot (Durafet III only) |
| 31086221 | O-ring for Integral Durafet Electrode or Remote Electrode Mounting Cable or External O-ring for Integral Meredian Electrode or Remote Electrode Cable Connector |
| 51452655-001 | Remote Mounting Kit for Wall, Pipe, or DIN Mounting |
| 51500768-001 | Remote Electrode Cable Connector Assembly (Meredian II Electrodes) — Includes O-rings and strain relief |
| 51500768-002 | Remote Electrode Cable Connector Assembly (HPW7000 Electrodes) — Includes O-rings and strain relief |
| 51452706-001 | Locking screw (locks sensor module to electrode or remote connector) |

Cordset

The cordset connection is an M12 female type that can be purchased directly from Honeywell or from multiple vendors including:

Turck Industries

Part Number RKV4T-6/S618 for a 6 m cordset with a stainless coupling nut

Part Number RK4T-6/S618 for a 6 m cordset with a nickel plated coupling nut

Phoenix Contact

Part Number SAC-3P-5.0-PUR/M12FSSH Stainless for a 5m cordset with a stainless coupling nut

Part Number SAC-3P-5.0-PUR/M12FSSH for a 5m cordset with a nickel plated coupling nut

Field Wiring connector

The Field Wiring Connector is an all-plastic screw terminal M12 female type that can be purchased directly from Honeywell or from multiple vendors including:

Turck Industries

Part Number B8141-0 for a M12 field wiring connector that accommodates customer supplied cable.

Phoenix Contact

Part Number SACC-M12FS-4CON-PG7 for a M12 field wiring connector that accommodates customer supplied cable.

7. Appendix: CE Mark Applications

In situations where the pH display appears to fluctuate (short deviations above 0.2 pH points) due to field wiring electrical noise, the noise may be reduced by making the additional ground connections as described in Figure 7-1.




Figure 7-1 Wiring for CE Mark Applications

8. Sales and Service

For application assistance, current specifications, pricing, or name of the nearest Authorized Distributor, contact one of the offices below.

ARGENTINA

HONEYWELL S.A.I.C.
BELGRANO 1156
BUENOS AIRES
ARGENTINA
Tel.: 54 1 383 9290

ASIA PACIFIC

HONEYWELL ASIA
PACIFIC Inc.
Room 3213-3225
Sun Kung Kai Centre
N° 30 Harbour Road
WANCHAI
HONG KONG
Tel.: 852 829 82 98

AUSTRALIA

HONEYWELL LIMITED
5 Thomas Holt Drive
North Ryde Sydney
NSW AUSTRALIA 2113
Tel.: 61 2 353 7000
AUSTRIA

HONEYWELL AUSTRIA

G.m.b.H.
Handelskai 388
A1020 VIENNA
AUSTRIA
Tel.: 43 1 727 800

BELGIUM

HONEYWELL S.A.
3 Avenue de Bourget
B-1140 BRUSSELS
BELGIUM
Tel.: 32 2 728 27 11

BRAZIL

HONEYWELL DO
BRAZIL
AND CIA
Rua Jose Alves Da
Chunha
Lima 172
BUTANTA
05360.050 SAO PAULO
SP
BRAZIL
Tel.: 55 11 819 3755

BULGARIA

HONEYWELL EOOD
14, Iskarsko Chausse
POB 79
BG- 1592 Sofia
BULGARIA
Tel.: 359-791512/
7940271 792198

CANADA

HONEYWELL LIMITED
THE HONEYWELL
CENTRE
300 Yorkland Blvd.
NORTH YORK,
ONTARIO
M2J 1S1
CANADA
Tel.: 800 461 0013
Fax: 416 502 5001

CZECH

REPUBLIC
HONEYWELL, Spol.s.r.o.
Budejovicka 1
140 21 Prague 4
Czech Republic
Tel.: 42 2 6112 3434

DENMARK

HONEYWELL A/S
Automatikvej 1
DK 2860 Soeborg
DENMARK
Tel.: 45 39 55 56 58

FINLAND

HONEYWELL OY
Ruukintie 8
FIN-02320 ESPOO 32
FINLAND
Tel.: 358 0 3480101

FRANCE

HONEYWELL S.A.
Bâtiment « le Mercury »
Parc Technologique de St
Aubin
Route de l'Orme
(CD 128)
91190 SAINT-AUBIN
FRANCE
Tel. from France:
01 60 19 80 00
From other countries:
33 1 60 19 80 00

GERMANY

HONEYWELL AG
Kaiserleistrasse 39
D-63067 OFFENBACH
GERMANY
Tel.: 49 69 80 64444

HUNGARY

HONEYWELL Kft
Gogol u 13
H-1133 BUDAPEST
HUNGARY
Tel.: 36 1 451 43 00

ICELAND

HONEYWELL
Hataekni .hf
Armuli 26
PO Box 8336
128 reykjavik
Iceland
Tel.: 354 588 5000

ITALY

HONEYWELL S.p.A.
Via P. Gobetti, 2/b
20063 Cernusco Sul
Naviglio
ITALY
Tel.: 39 02 92146 1

MEXICO

HONEYWELL S.A. DE
CV
AV. CONSTITUYENTES
900
COL. LOMAS ALTAS
11950 MEXICO CITY
MEXICO
Tel.: 52 5 259 1966

THE NETHERLANDS

HONEYWELL BV
Laaderhoogteweg 18
1101 EA AMSTERDAM
ZO
THE NETHERLANDS
Tel.: 31 20 56 56 911

NORWAY

HONEYWELL A/S
Askerveien 61
PO Box 263
N-1371 ASKER
NORWAY
Tel.: 47 66 76 20 00

POLAND

HONEYWELL Sp.z.o.o
Ul Domainewska 41
02-672 WARSAW
POLAND
Tel.: 48 22 606 09 00

PORTUGAL

HONEYWELL
PORTUGAL LDA
Edificio Suecia II
Av. do Forte nr 3 - Piso 3
2795 CARNAXIDE
PORTUGAL
Tel.: 351 1 424 50 00

REPUBLIC OF IRELAND

HONEYWELL
Unit 1
Robinhood Business
Park
Robinhood Road
DUBLIN 22
Republic of Ireland
Tel.: 353 1 4565944

REPUBLIC OF SINGAPORE

HONEYWELL PTE LTD
BLOCK 750E CHAI
CHEE ROAD
06-01 CHAI CHEE IND.
PARK
1646 SINGAPORE
REP. OF SINGAPORE
Tel.: 65 2490 100

REPUBLIC OF SOUTH AFRICA

HONEYWELL
Southern Africa
PO BOX 138
Milnerton 7435
REPUBLIC OF SOUTH
AFRICA
Tel.: 27 11 805 12 01

ROMANIA

HONEYWELL Office
Bucharest
147 Aurel Vlaicu Str.,
Sc.Z.,
Apt 61/62
R-72921 Bucharest
ROMANIA
Tel.: 40-1 211 00 76/
211 79

RUSSIA

HONEYWELL INC
4 th Floor Administrative
Building of AO "Luzhniki"
Management
24 Luzhniki
119048 Moscow
RUSSIA
Tel.: 7 095 796 98 00/01

SLOVAKIA

HONEYWELL Ltd
Mlynske nivy 73
PO Box 75
820 07 BRATISLAVA 27
SLOVAKIA
Tel.: 421 7 52 47 400/
425

SPAIN

HONEYWELL S.A
Factory
Josefa Valcarcel, 24
28027 MADRID
SPAIN
Tel.: 34 91 31 3 61 00

SWEDEN

HONEYWELL A.B.
S-127 86 Skarholmen
STOCKHOLM
SWEDEN
Tel.: 46 8 775 55 00

SWITZERLAND

HONEYWELL A.G.
Hertistrasse 2
8304 WALLISELLEN
SWITZERLAND
Tel.: 41 1 831 02 71

TURKEY

HONEYWELL
Otomasyon ve Kontrol
Sistemlen San ve Tic
A.S.
(Honeywell Turkey A.S.)
Emirhan Cad No 144
Barbaros Plaza C. Blok
Kat 18
Dikilitas 80700 Istanbul
TURKEY
Tel.: 90-212 258 18 30

UNITED KINGDOM

HONEYWELL
Unit 1,2 &4 Zodiac House
Calleva Park
Aldermaston
Berkshire RG7 8HW
UNITED KINGDOM
Tel.: 44 118 906 2600

U.S.A.

HONEYWELL INC.
INDUSTRIAL PROCESS
CONTROLS
1100 VIRGINIA DRIVE
PA 19034-3260
FT. WASHINGTON
U.S.A.
Tel.: 1-800-343-0228

VENEZUELA

HONEYWELL CA
APARTADO 61314
1060 CARACAS
VENEZUELA
Tel.: 58 2 239 0211

Honeywell

Industrial Measurement and Control
Honeywell
1100 Virginia Drive
Fort Washington, PA 19034